



**ON**



**OFF**

- 1 Stop recording
- 2 Log out on the tablet computer
- 3 Switch off the system at the touchpanel



**! Mind your USB flash drive**

## AV-SUPPORT

- Use **HELP** Report Problem
- Call +43-1-313 36 - 3003